



Step 1:

After filling the baler, open the lower door and place the wires on the bale.



Step 2:

Eject the bale onto a pallet or the teeth of a forklift.



Step 3:

Remove bales and store them outside.
Bales can be single or double stacked.
Approximately 8-10 bales can fit in one parking space.